


# HOW TO ORDER RS & SD SPIRALS


CALL FOR MORE INFO 1.866.940.0696

## Step 1. Know Your Spiral Pipe Diameter



RS and SD Spiral diffusers are manufactured to fit a specific size of spiral pipe

## Step 2. Figure the Height of the Diffuser




The height of the diffuser needs to be 4" less than the pipe diameter.

## Step 3. Finish Options


Galvanized is standard (G). Specify if you want Soft White (S).

## Step 4. How to Order (Applies to the RS and SD series)



RS52-12x6-10-G

When ordering your RS and SD diffusers, please call out the part number as follows:



For more information, call: 1.866.940.0696, or email: [sm@shoemakermfg.com](mailto:sm@shoemakermfg.com)